

SKY

(寸法単位=mm)

形式	呼び番号	外径	内径	高さ
SKY	14	22	14	5
SKY	16	24	16	5
SKY	18	26	18	5
SKY	20	28	20	5
SKY	22	30	22	5
SKY	22.4	30	22.4	5
SKY	23.5	31.5	23.5	5
SKY	25	33	25	5
SKY	28	35.5	28	5
SKY	28A	36	28	5
SKY	30	40	30	6
SKY	31.5	41.5	31.5	6
SKY	32	42	32	6
SKY	35	45	35	6
SKY	35.5	45	35.5	6
SKY	35.5A	45.5	35.5	6
SKY	36	46	36	6
SKY	40	50	40	6
SKY	45	55	45	6
SKY	45A	56	45	7
SKY	50	60	50	6
SKY	53	63	53	6
SKY	55	65	55	6
SKY	56	66	56	6
SKY	60	70	60	6
SKY	60A	71	60	7
SKY	63	73	63	6
SKY	65	75	65	6
SKY	67	77	67	6
SKY	70	80	70	6
SKY	71	80	71	6
SKY	75	85	75	6
SKY	80	90	80	6
SKY	85	100	85	9
SKY	86	100	86	8.5

(寸法単位=mm)

[illegible]